



Whitewall Tire Brown Buster

Instruction Sheet

Call us at 760-731-8301 for questions or email us at: sales@truespoke.net

To remove recurring brown stains on whitewall tires, please follow these instructions completely. The result will be well worth the effort. Don't throw-away or replace your tires because they have ugly brown stains.

This product may not work on tires that have turned yellow from the use or misuse of cleaning agents that have bleach or lye in them. Bleach and lye will cause permanent yellowing of whitewall tires.

For the best results, please follow each step completely. You can save your expensive whitewalls!

- 1) You will need Dawn© brand dishwashing soap, a 2-inch paint brush and a white terry cloth towel to clean and apply.
- 2) Remove the wheel and tire off of your car and lay it on the ground with the whitewall facing up.
- 3) Apply in direct sunlight, 70 degrees and up with no clouds in the sky.
- 4) Scrub the sidewall of your tire with Dawn© brand dishwashing soap to remove existing tire dressings. Let your tire dry in the sun.
- 5) Apply Brown Buster to the whitewall surface with your 2" brush. Apply a thick, smooth coat of Brown Buster. Allow the Brown Buster to soak in for 10 minutes.
- 6) Wipe-off the whitewall using a white towel. Do not use a colored towel. You should already see some brown stain on your towel!
- 7) Apply the second coat of Brown Buster to the whitewall with your 2" brush. Apply a thick, smooth coat of Brown Buster. Allow the second coat to soak-in for 10 minutes.
- 8) Wipe-off the whitewall using a white towel. Do not use a colored towel.
- 9) Apply the third coat of Brown Buster with your 2" brush to the whitewall. Apply a thick, smooth coat of Brown Buster. Allow the third coat to soak-in for 10 minutes.
- 10) Wipe-off the whitewall using a white towel. Do not use a colored towel.
- 11) Apply the fourth coat of Brown Buster to the whitewall using your 2" brush. Apply a thick, smooth coat of Brown Buster. Allow the fourth coat to soak-in for 10 minutes.
- 12) Wipe-off the whitewall using a white towel. Do not use a colored towel.
- 13) Allow the tire to sit in the direct sunlight. The Brown Buster will sink deep into the pores of the whitewall tire. Please allow the tire to sit in the sun, facing-up for one hour or more. Brown Buster will loosen-up the brown that is embedded deep into your whitewall.
- 14) Finally, move your tire into a cool area. Over the next few days, any brown material that is trapped in the pores of your tire will rise to the surface. The changes in temperature of 20 to 25 degrees will squeeze the brown stains out of the whitewall. Wipe the surface of your whitewall off with your white towel.

Maintenance: Do not scrub your clean whitewall with a brush as it will remove the Brown Buster that has been applied.

To Clean: Wash the sidewalls off with water, do not scrub. Wipe your tire with a dry white towel.

Brown Buster contains mineral oil, paraffin and a fragrance. Please email or call with any questions. Thank you.

Motorspot, Inc.
427 Industrial Way, Unit C
Fallbrook, California 92028



Telephone: 760-731-8303
Website: www.hobbycar.com
serving the collector car community since 1974